

APPLICATION INSTRUCTIONS FOR AIRSEPT AIR ODOR TREATMENT

SAFETY PRECAUTIONS: Keep out of reach of children. Avoid skin and eye contact. Wear safety glasses and gloves. Avoid breathing vapor.

FIRST AID INSTRUCTIONS: If skin contact occurs, wash with soap and water. Rinse with water. If eye contact occurs, flush with plenty of clean water. Seek medical assistance when in doubt.

AirSept Air Odor Treatment has been engineered to absorb the molecules that cause organic odor (for example, those caused by flood damage, water leaks, food/beverage spills, and pets). Odor Treatment is designed for use on automobile carpeting only, and may have an adverse effect on surfaces such as leather, suede, glass, wool, and vinyl. Cover these surfaces with covering paper and/or disposable Plastic Seat Cover. To prevent accidental drops from the nozzle or the sprayed headliner from falling onto these surfaces, cover the seats. As with any common chemical, always test the intended surface(s) for colorfastness by applying Air Odor Treatment to a small, hidden area first. **DO NOT SPRAY AIR ODOR TREATMENT BEHIND THE DASH, AS THE PRODUCT MAY PROVE HARMFUL TO COMPONENTS.**

INSTRUCTIONS:

1. Remove all floor and trunk mats, and rear seat. Vacuum clean the mats and the interior of the vehicle and trunk.
2. Verify that the vehicle has a dry interior and trunk. If any damp or wet areas are discovered, they will need to be completely dried prior to application of the AirSept Air Odor Treatment. Find the source of the moisture and correct it. In cases of food spills, make sure to completely clean up the spill.
3. Fill a four (4) ounce applicator bottle with AirSept Air Odor Treatment and attach it to the Ulti-Flex Pressure Spray Tool. Attach the Ulti-Flex to a compressed air line. **IF APPLYING AIR ODOR TREATMENT VIA 1-PINT BOTTLE WITH PUMP SPRAYER APPLICATOR, SKIP TO STEP 4.**



4. Turn vehicle on. Set the A/C controls to fan on high, mode on recirculate, and heat on high.
5. Starting at the front of the vehicle and working to the rear, apply AirSept Air Odor Treatment to the floorboard, floor mats, and under the seats. Spray the far side first and work back to the near side. Keep the applicator nozzle 12"-18" from the surfaces being treated.
6. Close the door and let the vehicle sit for 20 minutes, making sure to leave the car on and A/C controls set as described in Step 5.
7. Rinse the Ulti-Flex with warm water immediately after use to prolong the life of these tools. Be sure to spray warm water through the nozzle to rinse out any residual product still in the capillary tube, otherwise it will corrode the tool.
8. Open all doors, roll up the windows, shut off the engine and A/C controls. Remove all protective coverings.