

AIRSEPT COMPRESSOR TURNER TOOL

Use Instructions

Always follow manufacturer instructions when installing a new compressor.

1. Compressor must be secured prior to using tool.
2. If applicable, remove the protective cap in hub shaft.
3. Lubricate spacer and tool threads prior to each use with mineral oil.
4. Hand start threads for 2 turns prior to employing wrench. (See Fig 1.)
5. Do not exceed 90 ft/lbs of torque on tool.
6. Do not use an impact wrench on tool.
7. Apply steady force using a wrench or socket to rotate compressor. (See Fig 2.)
8. Rotate compressor following manufacturer instructions.
9. Remove tool from hub shaft (it may be necessary to apply a quick blow to the wrench to loosen the tool) and replace the protective cap in the hub shaft.
10. Clean the tool and store in a convenient location for next use.



Fig 1.



Fig 2.