

# Ulti-Flex Pressure Spray Tool

## OPERATING INSTRUCTIONS

### Materials Included:

1ea. Flexible Applicator Tool Assembly

1ea. 8 fl. oz./236ml Bottle, Empty

### Spray Applicator Tool Assembly:

Attach a compatible ¼” NPT air line quick connect fitting to the air gun.



*The “Ulti-Flex” spray tool works with any sprayable liquid product packaged in a compatible 4 or 8 ounce bottle or transfer the product into the supplied 8 ounce bottle for use with this tool.*

### General Instructions:

1. Place a drain pan under the work area and cover any areas that may be stained or damaged by the product being sprayed.
2. Shake the product bottle well then screw the bottle onto the cap on the tool’s pick-up tube.
3. Connect the tool to a compressed air source operating at 85 to 115 PSI.
4. Press the air gun trigger to activate air and product flow through the tool. Follow any relevant application instructions supplied by the product manufacturer. ***If product does not flow through the tool, remove the small green valve from the bottle cap, assure that it opens by rolling and squeezing it between two fingers the reinstall it in the cap.*** (See cleaning instructions.)

### Cleaning Instructions:

1. Residual product may clog the pick-up tube. Rinse with and spray warm water through the tool to remove any residual product on the tool or in the pick-up tube after every use. Remove the small green valve from the bottle cap and rinse it thoroughly while rolling and squeezing it between two fingers then reinstall it in the cap. If this valve is clogged, product will not flow through the tool.

### Caution:

**Spraying volatile, flammable or hazardous products may increase potential for harm. Ensure proper ventilation and spraying conditions prior to using potentially hazardous products. See applicable product warnings and instructions prior to spraying.**